



## PR 300T

### DMX CHART

| 2 Channels Mode | Function          | Function Control                         |
|-----------------|-------------------|------------------------------------------|
| CH1             | Dimmer            | 000-255: 0-100% dimmer                   |
| CH2             | Color Temperature | 000-255: Color temperature 2800K - 6500K |

| 5 Channels Mode | Function          | Function Control                         |
|-----------------|-------------------|------------------------------------------|
| CH1             | Dimmer            | 000-255: 0-100% dimmer                   |
| CH2             | Strobe            | 000-255: Strobe with speed increasing    |
| CH3             | WW                | 000-255: 0-100% warm white dimmer        |
| CH4             | CW                | 000-255: 0-100% cold white dimmer        |
| CH5             | Color temperature | 000-255: Color temperature 2800K - 6500K |



## PR 300W

### DMX CHART

| 1 Channel Mode | Function | Function Control       |
|----------------|----------|------------------------|
| CH1            | Dimmer   | 000-255: 0-100% dimmer |

| 2 Channels Mode | Function | Function Control                      |
|-----------------|----------|---------------------------------------|
| CH1             | Dimmer   | 000-255: 0-100% dimmer                |
| CH2             | Strobe   | 000-255: Strobe with speed increasing |

| 3 Channels Mode | Function    | Function Control                      |
|-----------------|-------------|---------------------------------------|
| CH1             | Dimmer      | 000-255: 0-100% dimmer                |
| CH2             | Dimmer fine | 000-255: 16 bit dimmer                |
| CH3             | Strobe      | 000-255: Strobe with speed increasing |



## PR 300C

### DMX CHART

| 1 Channel Mode | Function | Function Control       |
|----------------|----------|------------------------|
| CH1            | Dimmer   | 000-255: 0-100% dimmer |

| 2 Channels Mode | Function | Function Control                      |
|-----------------|----------|---------------------------------------|
| CH1             | Dimmer   | 000-255: 0-100% dimmer                |
| CH2             | Strobe   | 000-255: Strobe with speed increasing |

| 3 Channels Mode | Function    | Function Control                      |
|-----------------|-------------|---------------------------------------|
| CH1             | Dimmer      | 000-255: 0-100% dimmer                |
| CH2             | Dimmer fine | 000-255: 16 bit dimmer                |
| CH3             | Strobe      | 000-255: Strobe with speed increasing |