

CYCLOPS LIGHTING

SHOT FOUR

DMX CHART

Channel (CH)	Function	Value Range	Effect and Description
CH1	Shot 1	0-127	OFF
		128-255	SHOT 1 TRIGGER ON
CH2	Shot 2	0-127	OFF
		128-255	SHOT 2 TRIGGER ON
CH3	Shot 3	0-127	OFF
		128-255	SHOT 3 TRIGGER ON
CH4	Shot 4	0-127	OFF
		128-255	SHOT 4 TRIGGER ON
CH5	All Shots (All 4)	0-127	OFF
		128-255	ALL SHOTS TRIGGER ON
CH6	Sequence 1 Left to Right	0-127	OFF
		128-255	Sequential Trigger: Left to Right (Shot 1-2-3-4)
CH7	Sequence 2 Right to Left	0-127	OFF
		128-255	Sequential Trigger: Right to Left (Shot 4-3-2-1)
CH8	Sequence 3 In to Out	0-127	OFF
		128-255	Sequential Trigger: In to Out (Shot 2/3 - 1/4)